







Thanks for choosing our device, please read

the user guide carefully before using.







Search and download Search and download "VervFitPro" from the Apple Store or

Scan the QR code and download It probably has a problem to open the link with WeChat or other scan tools, please copy the link and open it through browse



1. The iBrace'07 must be activated by charging before initial use, and then charge iBrace'07 to ensure normal nower supply. The hand ring will automatically nower on





3 Mount iRrace'07 horly into the slot of the wrist stran-



2. Touch to use

[Slide up and down]: Switch mode, wake up the screen: [Click the screen]: Switch data types at the same level. enter details, click the button [Hold the screen]: Enter the corresponding function operation (such as deleting information)

[Click the button]: Return to the upper level, return to the time home page, interrupt operation [Hold the button]: Enter the corresponding function oneration (such as countdown)

 When clicking type switch (same level): data and unit appear in floating; 2. If there is no next/previous content when sliding up and down, the screen will shake a bit and the motor will vibrate very slightly. 3. Click to enter the function. If there is no content, the screen will shake up and down and the motor will vibrate very slightly.

3. open app "VeryFitPro", and pair it with iBrace'07



ake sure the Bluetooth of smart phone is ON, open app "VeryFitPro". When selecting the right band from the search list, please slide the screen of wristband to wake up he device and then complete connecting.

1. Interface

Time mode -> Sports mode -> Mindfulness training -> Information mode -> Music mode -> More mode



Note: Music mode (the ann will not turn on this function or display it)

2. Time/Data mode



Snorts mode



Note: Walk, Run, Bike, Hike, Treadmill, Workout, Basketball, Badminton (8 default); 6 optional in the app; Tennis, Football, Climb, Spinning, Yoga, Dance 3.1. Soorts underway mode

10:20 AN ♥ 10:20 AN ♪ 10:20 AN ◆ 10:20 AN ○ 10:20 AN ○ 10:20 AN ♪ 130 56789 1245 34.5 8'45" 8'45" BPM Steps Kcal KM Pace AVG PACE

12:34.56 12:34.56 12:34.56 12:34.56 12:34.56 💌 Note: According to different sports types, the content displayed is slightly different: Sports music control mode(the app will not turn on

When the ann is connected and the bike snorts starts synchronously with the app, it will display the page and distance Otherwise it will not display

3.2. Sports pause mode

this function or display it):



Note: In the sports countdown mode, [Release the button ■ 1 to exit the sports countdown mode:

[Press and hold the button \blacksquare] to prompt the sports countdown 3, 2, 1. Keep holding the button to exit the sports mode.

3.3. Sports end mode

(1) If the enorte time is less than 5 minutes



②

[Click 8] to return to [Exercise mode - Home page] [Click 2] enter [Sports data display mode]

(2) If the exercise time is more than 5 minutes



[Click the screen/main button] enter [Snorts data display mode]

3.4. Sports data display mode



789 8'45"

3.5. Sports event reminder

(1) Reminder of exiting from Sports mode upon a period of no actions

Note: Exiting from sports mode upon a period of no actions in 15 seconds only includes three sports of Valla, Run and Treadmill.

When the user remains inactive in 10 minutes, it will remind the user 15 seconds before the end, that a bright screen will appear and the motor will vibrate once.

(2) Reminder of force exiting from Sports mode due to full RAM



Note: The sports mode can last up to 6 hours

83

iBrace'07

smart action's.

BLUEGIGIT" BE DOMINANT.



www.bluediait.online



3) Reminder of force exiting from Sports made due to low battery

the app is actively launching a sports. When app and wrist band are

disconnected, there shall be interface for the user to make selection



Note: [Click] to confirm the reminder of force exiting from Sports

3.6. Abnormal operations during sports If the wrist band needs to operate in a state (pause, resume, end.) when



Reminder of waiting for selection Description: Enter the waiting reminder and the motor vibrates Only the sports initiated by app will have this reminder.



Description:Time out after 15s. If app and ble device are successfully to exit the reminder of waiting. And the operation will be executed

connected within 15s, exit the reminder of waiting. The operation will be ecuted immediately. If the connection is not successful within 15s, force

the icon of searching phone will not be displayed.

3.7. It will not enter Sports mode due to low battery

Note: 1. When entering this mode, the motor vibrates slightly; Charge First 2. The reminder will occur when a user tries to start the sports with the device in low battery mode

Music control mode



[Hold

/ ▼ for 2s] enter music control (volume up and down) mode; [Hold ◀+/ ◀- for 2s] return to music control (next and previous) mode If any turns off the music function, this interface will not be displayed When APP turns on the music function, if there is no bluetooth connection between the wrist band and the mobile phone, the wristband displays

5. More modes



T 4

Note: When the app does not turn on the function of searching phone,

[Click] enter Do Not Disturb mode; [Click] enter Stopwatch mode. [Click 10] enter Camera mode; [Click 10] enter Dial mode, with 5 dials, which can be replaced by clicking the screen. [Click >] enter raising wrist to brighten the screen; [Click]

enter Alarm switch. [Click] enter Heart rate switch; [Click &] enter Timeline details, up to 50 timeline details. [Click (1)] enter Shutdown mode: [Click 1] enter Phone searching mode.

> 6. Reminder mode (1) Call reminder

V/IKV 1566236

End condition: Click a or [Click the main button] to end Call reminder. (2) Message reminder

Note: [Click the screen] the information will switch to the next page, and the page will be switched cyclically. If there is no operation, the screen will be off after 5s; [Click the main button] exit reminder (save information after exiting reminder). (3) Alarm clock

12:45

End condition: [Time out for 10s] (except that the Wake-up alarm clock times 0.0

(4) Long sitting reminder

(5) Target completion reminder

End condition: [Time out for 15s] / [Slide up and down] / [Click the main button].



End condition: [Time out for 10s] / [Slide up and down] / [Click the main button].

Note: [Slide up and down] / [Click the main button] end reminder

Closing condition: [Slide up and down] / [Click the main button]

Low battery Ultra-low battery

7. Low battery reminder mode

8. Device abnormality reminder mode



-01 means the abnormality of acceleration sensor -02 means the abnormality of heart rate sensor

-03 means the abnormality of touch key IC -04 means the abnormality of flash **Basic Specifications**

Maximum transmit power: 0.72dBm

Model No.: iBrace'07 Battery Capacity: 90mAh Working Voltage: 4 35V Host weight: 22a Sync: Bluetooth 4.0 Working temperature: -20 ℃-40 ℃ Waterproof: IP68 Charging time: 1~2h Working Time: 7days Product frequency band: 2402-2480MHz

Declaration of toxic and hazardous substances in



The device meets the EU ROHS criterion, Please refer to IEC 62321 FU ROHS Directive 2011/65/FU and revised directive

Wearing and Maintenance



 iBrace'07 is designed for you to wear throughout the day. So please follow a few brief instructions when you are wearing and maintaining your iBrace'07. To keep your iBrace'07 clean and your skin comfortable, we put forward the following tips:

 Regularly clean your wrist and the iBrace'07, especially after sweating in the exercise or being exposed to substances such as soap or detergen which may attach on the internal side of the iBrace'07.

 Do not wash the iBrace'07 with household cleanser. Please use scapless detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

FAQ

 Failed to find the iBrace'07 when pairing. Make sure the Bluetooth of smart phone is ON, and smart phone OS.

Android 4.4 & Above. iOS 8.0 & Above.

(2) Make sure the distance between phone and iBrace'07 is within 0.5meter iBrace'07 is among the normal Bluetooth communication distance range(within 7meter) after pairing finished. 3 Make sure iBrace'07 is not under low battery. If there is still a problem

(2) Reboot mobile phone or re-start the Bluetooth service, then it works normal.

after fully charged, please contact us. ◆ Failed to connect with Bluetooth occasionally 3 Caused by the abnormality of Bluetooth service when it restarted on the phone

 How to restore factory defaults Make sure iBrace'07 is connected with smart phone, go in the App. enter "device- more", and choose "reboot device".

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

that may cause undesired operation for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits

are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

Reorient or relocate the receiving antenna.

RISK OF EXPLOSION IF RATTERY IS REPLACED.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

/ Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

F© (E 💆 🗵

VervEitPro

Backup_of_ibrace'08 iBrace '07 - Packing Monday, October 14, 2019 6:54:49 PM

