

# iBrace'08


smart actions' dominates.

### 1. Each function page of this product

#### 1.1 Weather, time, Bluetooth icon, date, temperature, battery



#### 1.2 Step count 1.3 Caloric consumption



#### 1.4 distance



#### 1.5 Health (heart rate, blood pressure, blood oxygen)



#### 1.6 Sleep



#### 1.7 Sports (climbing, running, walking, swimming, basketball, table tennis, cycling, badminton, football)



#### 1.8 notification



#### 1.9 More (stopwatch, find phone, about, QR code, factory reset, shutdown)



#### 1-10 Alert message (step goal, sedentary reminder, charging icon, call notification, drinking reminder, remote photo, looking for bracelet)



### 2. Brief operation of this product

#### 2.1 Touch function

Short press: wake up the screen and switch between different function interfaces in turn;  
 Long press: Quickly return to the time interface or enter the secondary menu interface in other interfaces

#### 2.2 Charging

Take the host out of the strap, insert the wristband into the USB port or plug it into the charging head with the USB jack, and then plug the charging head into the socket to charge it normally.

When the bracelet is charging, the "Charging" interface will pop up. The screen will display "full" when the battery is fully charged.

Connect the DC when the bracelet is turned on/off, and the PC can be charged.

#### 2.3 Health data

##### Health data opening method

Step and sleep: step by step and sleep default when the bracelet is turned on

Heart rate: Click the touch button to the heart rate interface, the wristband heart rate light is on and the heart rate detection is on.

Blood pressure: Click the touch button to the heart pressure interface, the wristband heart rate light is on and the blood pressure detection is on.

Blood oxygen: Click the touch button to the heart rate interface, the wristband heart rate light is on and the blood oxygen test is turned on.

##### Sports mode test method

##### Open various sports modes

After saving the data after each sport mode, the following two conditions must be met.

If this condition is not met, the message "small motion data is not saved."

- Exercise to 300 steps
- The exercise time is more than 3 minutes, the first time is a long press pause, the second long press is to save,

#### Health data synchronization

After successful connection with the APK Bluetooth, the wristband end step/sleep/sports/heart rate, blood pressure, blood oxygen data will be automatically synchronized to the mobile phone in real time, open the main interface of the APK and slide the interface to view the data, click the upper left synchronization button to synchronize the data.

##### Health data monitoring

Steps: Monitor the amount of exercise around the clock and clear the tachometer data at 12 o'clock in the evening.

Sleep: Sleep monitoring time is from 22:00 to 08:00, sleep data is displayed on the wristband, and sleep data is generated at night. The next day, you can connect to Bluetooth LiveSync to your phone APK. (Note: Synchronization Prerequisite: APK Binding Bracelet)

#### 2.4 Bluetooth connection

##### 2.4.1 Transfer/download

- Download through the application market
- Android: application treasure, pea pod and other application market search distribution download
- IOS side: App Store search distribution download
- through the bracelet QR code scan download

IOS

Android

Android: Scan the QR code via QQ, WeChat or other applications, and link to the download interface to download.

IOS side: Scan the QR code through QQ, WeChat or other applications, and directly link to APPSTORE to download.

Installation completion icon as shown

2.4.2 log in  
 After downloading the distribution, open the APK to automatically log in and view my, the user changes their information.

2.4.3 Bluetooth connection  
 After the bracelet is turned on, Bluetooth is always in the search state. When the APK is downloaded, click Add Device, select the bracelet device name (the Bluetooth name of the bracelet is: AB310H), and click the Bluetooth device to connect successfully.

After the Bluetooth connection is successful  
 1)View the Bluetooth name of the bracelet at the device unbind

2. The bracelet time is synchronized with the time of the mobile phone, and the APK

clicks to find the bracelet, the bracelet shines brightly and the corresponding prompt icon is displayed

Bluetooth auto reconnect  
 11. There is no reminder beyond the Bluetooth connection range. When the bracelet reaches the valid range of Bluetooth connection, Bluetooth will automatically reconnect; Close the application background or restart the phone or click the one-button cleaning that comes with the phone, and enter the distribution bracelet again. Bluetooth will automatically reconnect within the valid range of Bluetooth connection.

5. Other functions  
 The following functions can be achieved only after successfully logging in to the APK and the Bluetooth connection is successful.

Find the bracelet  
 Click to find the bracelet, the bracelet glows brightly and the corresponding prompt icon is displayed.

Notice  
 Support call notifications, SMS notifications, and application notifications that are enabled in the message push settings (example: Open the call notification in the APK. When the mobile phone receives an incoming call, the wristband vibrates on the screen to remind the user, the interface will display the caller icon, click the touch button Will hang up the call);  
 Do not disturb mode  
 When the Do Not Disturb mode is enabled, all notification reminders that are turned on in the settings besides the alarm clock, when the push notification is sent, there will

be no automatic bright-screen vibration reminder on the wristband end.

Sedentary reminder  
 Set the start to end time period and sedentary time interval (minutes), threshold (steps), click to enter the repeat setting to select the sedentary reminder date (week), when the sedentary time arrives, the bracelet end brightly vibrates and displays for a long time. Sitting icon.

Drinking water reminder  
 Set the start to end time interval and the water time interval (minutes), click to enter the repeat setting to select the water reminder date (week), when the drinking time arrives, the bracelet end brightly vibrates and displays the drinking water icon.

Alarm reminder  
 The APK side clicks the alarm reminder setting to add the alarm time. When the alarm time arrives, the bracelet end vibrates and the screen prompts and displays the alarm icon.

Reminder mode  
 Bright screen: When the mobile phone APK terminal sets the alarm time to arrive or receives the push message, the wristband end only highlights the screen;  
 Vibration: When the mobile phone APK terminal sets the alarm time to arrive or receives the push message, the wristband end only vibrates and alerts;

Bright screen + vibration: When the mobile phone APK side sets the alarm time to arrive or receives the push message, the bracelet end bright screen + vibration reminder;

Raise your hand to brighten:  
 Raise the hand to brighten the screen: Turn on the hand to brighten the screen, raise your hand so that the bracelet is tilted inward to face the front of you, and the end of the bracelet is bright;

Raise the hand to brighten the screen: Turn on the hand to brighten the screen, raise your hand so that the bracelet is tilted inward to face the front of you, and the end of the bracelet is bright;

Bluetooth camera:  
 Click on the photo on the APK side, the phone will enter the camera interface, and the camera icon will appear on the bracelet.

Unit setting:  
 The APK side switches the metric system and the temperature in degrees Celsius and Fahrenheit, and the bracelet will be updated simultaneously.

Unbinding equipment:  
 Open the split, in the "More" interface, click "Device Unbind" will pop up "OK to unbind the Bluetooth device?", select "OK" to unbind (on the premise of successful Bluetooth connection).

- Platform compatibility:
- Android4.2 or IOS 8.0 and above devices that support Bluetooth 4.0;
  - When using for the first time, please connect the charger to activate the bracelet;
  - Please confirm whether the network is abnormal when downloading and transferring;
  - Bluetooth connection:

A Please make sure that the Bluetooth of the mobile phone is turned on and the wristband is turned on.

B When searching for Bluetooth, please make sure that the bracelet is not bound by

other accounts;  
 When C searches for Bluetooth, the bracelet and the mobile phone are as close as possible.

5. If the hand ring does not receive the push message, please make sure that the APK is running in the background and the message notification is on (the auxiliary function needs to be turned on);

6. If the exercise, sleep, and heart rate data are not synced to the APK, try disconnecting the Bluetooth and reconnecting from the APK;

7. The Bluetooth connection is abnormal, unable to enter the APK, please try to enter the mobile application management to clean up this APK cache data;

8. Before binding the bracelet to another account, you need to unbind it with the current account.

9. If the bracelet cannot be illuminated, connect the bracelet to the charger.

A Quality Guaranteed Product  
 Perfect choice for your lifestyle. Enhance your life through Blue.

**BLUEDIGIT "BE DOMINANT"**  
 ©Copyright © a product of Aihua Group All rights reserved.  
 B2P and B2B2C "Be Dominant" was the registered trademark of Aihua.  
 The name "Be Dominant" B2C "Be Dominant" on the bracelet can be not authorized to use without permission from Aihua.

MADE IN CHINA  
 1 Year Limited Warranty.  
 \*Warranty does not include of any handling  
 or wear items, some special situations due to rough usage.

www.bluedigit.online

Bluetooth Icon and Logo are the properties of their respective owners.

Designed by Aihua